



# Tubular Blockout Installation Instructions

---

**Tools Needed:** Phillips Head Screwdriver.

## STEP 1

Unscrew the existing trim ring and lay the steel ring inside the trim ring underneath the 3 tabs. Be careful not to twist the ring, the ring must lay flat inside the trim ring.

## STEP 2

Reinstall the trim ring.

## STEP 3

Take the rod out, pull out the pin, pull out the inner rod, and reinsert it into the other end. Then properly line up the hole in the smaller rod to the hole in the larger rod when reinserting the pin.

## STEP 4

Take the rod and insert it into the disc socket, then attach the disc to the trim ring with the magnets. Once the disc attaches to the trim ring, gently slide the rod out. You have now darkened your room.

## STEP 5

To take the disc out, take the rod slide it gently into the socket on the disc and pull it straight down.