

## STEP 1

Unscrew the existing trim ring and lay it down on a flat surface.

## STEP 2

The Blockout disc has a loop “fuzzy” Velcro side pre-attached.

**NOTE:** *There is also circular Velcro hook tabs that include peel and stick backing.*

## STEP 3

Flip over the Blockout disc and center it over the trim ring (utilizing the Velcro side)

**NOTE:** *The Blockout disc will be about a half inch smaller than the trim ring.*

## STEP 4

After determining proper alignment, lift up the Blockout disc; peel the backing off of all the sticky tabs (Make sure the tabs are still attached when you peel off the backing). Reposition the Blockout disc on the trim ring by repeating Step 3. Then press firmly around the perimeter.

**NOTE:** *This will create adhesion between the sticky tabs and the trim ring.*

## STEP 5

Remove the Blockout disc from the trim ring. Reattach the trim ring to the ceiling.

## STEP 6

Take the rod out of the bag and pull out the inner tube to align the small holes on both ends of the tubes. Then insert the pin all the way through both tube holes to hold the two tubes in place.

## STEP 7

To take the disc out, take the rod and slide it gently out of the socket on the Blockout disc then pull it straight down.

## STEP 8

Once engaged, slide the rod gently out of the socket on the Blockout disc.

## STEP 9

To take the disc down and unblock the light, gently insert the rod into the Blockout disc socket and pull it straight down.